



- 15. 영사막 + 가림막 (SCREEN + COVER CURTAIN)
- 14. 하늘막 (CYCLORAMA)
- 13. 검정하늘막 (BLACK CYCLORAMA)
- 12. 장치봉 4 (#4 SET BATTEN)
- 11. 하늘막상단조명 + 머리막 2 (UPPER CYC. LIGHT + #2 HOUSE BORDER)
- 10. 장치봉 3 (#3 SET BATTEN)
- 09. 끝막 3 (#3 DRAW CURTAIN)
- 08. 장치봉 2 (#2 SET BATTEN)
- 07. 조명봉 2 (#2 LIGHT BATTEN)
- 06. 끝막 2 (#2 DRAW CURTAIN)
- 05. 장치봉 1 (#1 SET BATTEN)
- 04. 조명봉 1 (#1 LIGHT BATTEN)
- 03. 보더라이트 + 머리막 1 (BORDER LIGHT + #1 HOUSE BORDER)
- 02. 끝막 1 (#1 DRAW CURTAIN)
- 01. 면막 (HOUSE CURTAIN)
- 00. 영점선 (ZERO LINE)
- 01. 롤스크린 (ROLL SCREEN)
- 02. 장치봉 0-1 (#0-1 SET BATTEN)
- 03. 장치봉 0 (#0 SET BATTEN)
- 04. 앞무대조명 (APRON LIGHT)
- 05. 현수막판 (PLACARD PANEL)