



- 05. 현수막판 (PLACARD PANEL)
- 04. 앞무대조명 (APRON LIGHT)
- 03. 장치볼 0 (#0 SET BATTEN)
- 02. 장치볼 0-1 (#0-1 SET BATTEN)
- 01. 롤스크린 (ROLL SCREEN)
- 00. 영검선 (ZERO LINE)
- 01. 하우스 커튼 (HOUSE CURTAIN)
- 02. 하우스 커튼 (HOUSE CURTAIN)
- 03. 본더라이프 트레일 1 (BORDER LIGHT + #1 HOUSE BORDER)
- 04. 조명볼 1 (#1 LIGHT BATTEN)
- 05. 조명볼 2 (#2 LIGHT BATTEN)
- 06. 조명볼 2 (#2 DRAW CURTAIN)
- 07. 조명볼 2 (#2 SET BATTEN)
- 08. 조명볼 2 (#2 SET BATTEN)
- 09. 조명볼 3 (#3 SET BATTEN)
- 10. 조명볼 3 (#3 DRAW CURTAIN)
- 11. 조명볼 4 (#4 SET BATTEN)
- 12. 조명볼 4 (#4 SET BATTEN)
- 13. 하층막 (BLACK CYCLORAMA)
- 14. 하층막 (CYCLORAMA)
- 15. 영상막 + 가림막 (SCREEN + COVER CURTAIN)

