



- -02. 현수막봉 (PLACARD BATTEN)
- -01. 앞무대조명+ 머리막 1 (APRON LIGHT + #1 HOUSE BORDER)
- 00. 영점선 (ZERO LINE)
- 01. 방화막 (SAFETY CURTAIN)
- 02. 모양막 (CONTOUR CURTAIN)
- 03. 끌막 1 (#1 DRAW CURTAIN)
- 04. 보더리프트 1 + 머리막 2 (#1 BORDER LIGHT + #2 HOUSE BORDER)
- 05. 조명봉 1 (#1 LIGHT BATTEN)
- 06. 조명봉 1 (#1 SET BATTEN)
- 07. 조명봉 2 (#2 SET BATTEN)
- 08. 조명봉 3 (#3 SET BATTEN)
- 09. 끌막 2 (#2 DRAW CURTAIN)
- 10. 조명봉 4 (#4 SET BATTEN)
- 11. 천장음향반사판 1 (#1 ACOUSTICAL SHELL-CEILING)
- 12,13. 측면음향반사판 1,2 (#1,2 ACOUSTICAL SHELL-SIDE WALL)
- 14. 영사막 + 가림막 (SCREEN + COVER CURTAIN)
- 15. 다리막 1 (#1 HOUSE LEG)
- 16. 보더리프트 2 + 머리막 3 (#1 BORDER LIGHT + #3 HOUSE BORDER)
- 17. 조명봉 2 (#2 LIGHT BATTEN)
- 18. 조명봉 5 (#5 SET BATTEN)
- 19. 조명봉 6 (#6 SET BATTEN)
- 20,21. 측면음향반사판 3,4 (#3,4 ACOUSTICAL SHELL-SIDE WALL)
- 22. 천장음향반사판 2 (#2 ACOUSTICAL SHELL-CEILING)
- 23. 끌막 3 (#3 DRAW CURTAIN)
- 24. 조명봉 6-1 + 머리막 4 (#6-1 SET BATTEN + #4 HOUSE BORDER)
- 25. 조명봉 7 (#7 SET BATTEN)
- 26. 후사막 (REAR SCREEN)
- 27. 조명봉 3 + 머리막 5 (#3 LIGHT BATTEN + #5 HOUSE BORDER)
- 28,29. 측면음향반사판 5,6 (#5,6 ACOUSTICAL SHELL-SIDE WALL)
- 30. 천장음향반사판 3 (#3 ACOUSTICAL SHELL-CEILING)
- 31. 조명봉 8 (#8 SET BATTEN)
- 32. 조명봉 9 (#9 SET BATTEN)
- 33. 다리막 2 (#2 HOUSE LEG)
- 34. 후면음향반사판 (ACOUSTICAL SHELL-BACK WALL)
- 35. 보더리프트 4 + 머리막 6 (#4 BORDER LIGHT + #6 HOUSE BORDER)
- 36. 조명봉 4 (#4 LIGHT BATTEN)
- 37. 조명봉 10 (#10 SET BATTEN)
- 38. 조명봉 11 (#11 SET BATTEN)
- 39. 조명봉 12 (#12 SET BATTEN)
- 40. 하늘막상단조명 + 머리막 7 (SKY CYC. LIGHT + #7 HOUSE BORDER)
- 41. 끌막 4 (#4 DRAW CURTAIN)
- 42-45. 조명봉 13-16 (#13 - #16 SET BATTEN)
- 46. 흑막 (BLACK CYCLORAMA)
- 47. 조명봉 17 (#17 SET BATTEN)
- 48. 하늘막 (CYCLORAMA)